Vox Centrex Yealink T46 User Guide

Author: Dale Ellwood


Department: Vox Telecom R&D

Date: September 2014

TABLE OF CONTENTS

Handset Description	Page 2
Keypad Lock	Page 5
Directory	Page 5
Adding an Entry	Page 5
Edit or Delete an Entry	Page 5
Black List	Page 6
Dialling from Directory	Page 6
Making a Call	Page 6
Placing call on Hold	Page 6
Making 2 nd Call	Page 6
Answering a call	Page 7
Denying an Incoming Call	Page 7
Call History	Page 7
Do Not Disturb (DND)	Page 7
Call Pick Up	Page 7
Call Forwarding	Page 8
Call Waiting	Page 8
Call Transfer	Page 9
Blind Transfer	Page 9
Blind Transfer	Page 9
3 Way Conference	Page 9
Voicemail	Page 10
Customer Self-Care	Page 11

Handset Description



	Item	Description
		Shows information about calls, messages, soft keys,
		time, date and other relevant data:
		Call information—caller ID, call duration
1	LCD Screen	• Icons (for example, 😑)
		Missed call text or second incoming caller information
		Prompt text (for example, "Saving config file!")
		Time and date
2	Power Indicator LED	Indicates phone power and some feature statuses.
(3)	Line Kour	Use these keys to activate up to six accounts and assign
0	Line Keys	various features.
4	HEADSET Key	Toggles and indicates the headset mode.
4	MUTE Key	Toggles and indicates mute feature.
	MESSAGE Key	Accesses voice messages.
(5)	HOLD Key	Places a call on hold or resumes a held call.
9	REDIAL Key	Redials a previously dialed number.
	TRANSFER Key	Transfers a call to another party.
6	Speakerphone Key	Toggles the hands-free speakerphone mode.
7	Value - Kana	Adjusts the volume of the handset, headset, speaker,
	Volume Key	and ringer.
		Provides the digits, letters and special characters in
8	Keypad	context-sensitive applications.
	$\odot \odot \odot \odot$	Scroll through the displayed information.
9	OK OK	Confirms actions or answers incoming calls.
	×	Cancels actions or rejects incoming calls.
(10)	Soft Keys	Label automatically to identify their context-sensitive
(III)	3011 Keys	features.

Icon Instruction

Icons	Description
	Ringer volume is 0
	Keypad Lock
+	Received Calls
↑	Placed Calls
•	Missed Calls
*	Recording box is full
R	A call cannot be recorded
•	Recording starts successfully
X	Recording cannot be started
Œ	Recording cannot be stopped
*	Bluetooth
3.	Bluetooth headset is both paired and connected
	Conference
<u>0</u>	The contact icon
•	The default caller photo

Icons	Description
	Ringer volume is 0
	Keypad Lock
+	Received Calls
†	Placed Calls
•	Missed Calls
*	Recording box is full
R	A call cannot be recorded
•	Recording starts successfully
×	Recording cannot be started
Œ	Recording cannot be stopped
*	Bluetooth
3.	Bluetooth headset is both paired and connected
	Conference
<u>0</u>	The contact icon
1	The default caller photo

Keypad Lock

	ock the keypad:
	Long Press the # key The icon will be displayed on the top right corner of the idle screen.
Γo u	nlock the keypad:
	Press any navigation key, enter the PIN and press OK. "Default PIN is 1122"
Гос	hange the default PIN:
	Press MENU->Basic Settings->Phone Unlock Pin Enter the current Pin. "Default = 1122" Use the navigation key to scroll down. Enter the new Pin Use the navigation key to scroll down. Confirm the new PIN. Press Save
Dire	ectory:
۱۵۵i	ng an entry
4uui	
	Press Directory-> Local Directory-> Select the Contact Group-> Ok Press Add soft key; enter the Name, Office/Mobile number of the contact from the keypad. Use the 123 soft key to select between numeric and upper/lower case alphanumeric modes. Press Save soft key to add the contact or Cancel soft key to cancel the change.
	Press Directory-> Local Directory->Select the Contact Group->Ok Press Add soft key; enter the Name, Office/Mobile number of the contact from the keypad. Use the 123 soft key to select between numeric and upper/lower case alphanumeric modes. Press Save soft key to add the contact or Cancel soft key to cancel
	Press Directory-> Local Directory-> Select the Contact Group-> Ok Press Add soft key; enter the Name, Office/Mobile number of the contact from the keypad. Use the 123 soft key to select between numeric and upper/lower case alphanumeric modes. Press Save soft key to add the contact or Cancel soft key to cancel the change.

Caller	s added to the Black List will go straight to your voicemail.
	Press Menu Use the navigation key to select Directory and press OK Use the navigation key to select Blacklist and press OK Follow the steps above to add, edit or delete numbers.
Dialli	ing from a Directory
	Press Directory-> Local Directory-> Select the Contact Group-> Ok Use the navigation key to highlight the entry you want dial. Press the Send or OK button.
Mak	ring a call
To ma	ake a phone call:
	Pick up the handset, the icon will be showed in the idle screen. Press the Speaker button, icon will be showed in the idle screen. Press the Headset button if the headset is connected to the Headset Port in advance. The icon will be showed in the idle screen. Enter the number using the keypad. Press Ok, # or Send
	You can also dial the number first, and then choose the method you se to speak to the other party.
Plac	cing a Call on Hold
	While on an active call, press the Hold button. To retrieve the held call, press the Resume button.
To a	ctive a 2 nd or 3 rd call:
	Place the 1 st call on Hold . Select another Line Key . Dial the number and press Send or OK . To toggle between two calls on hold press SWAP . Toggle between 3 held calls by pressing the associated line button or use the navigation button and press Resume

Black List

Answering a call

Answering an incoming call

If you are not on an active call, lift the handset, press the Speaker button
Answer soft key to answer using the speakerphone or press the
Headset button to answer using the headset.
If you are on an active call, press the Line key to answer the 2 nd call.
This will place the 1 st call on Hold and you can toggle between the calls by pressing the associated Line button .

Note: During the conversation, you can alternate between Headset, Handset and Speakerphone by pressing the corresponding buttons or picking up the handset.

Denying an incoming call

Press Reject soft key to send the call to your voicemail.
Press Forward to redirect the call to another destination, enter
the destination and press Send .

Call History

To access the handset call logs

Press the History soft key.
Use the navigation button to scroll to All Call, Placed Calls, Received
Calls, Missed Calls or Forwarded Calls.
Use the navigation key to select an entry.
Press Send to dial the number.
Press Options to check the detail of the call, add it to the phone book or black list or to delete the entry.

DND (Do Not Disturb)

Note: All calls will be directed to your voicemail when DND is active.

Press DND soft key to active DND Mode. The	icon will display in the
top right corner of the display.	
Dance DND and bearing to departments DND and	_l _

☐ Press **DND** soft key again to deactivate DND mode.

Call Pick Up

Press the flashing BLF Button.
To answer a call ringing at another extension in the same pickup group, dial *78, use the GPickup softkey or press the Pick Up button if
configured.
To answer a call ringing at another extension not in the same pickup
group, dial *78 + extension number or use the DPickup softkey

Call Forwarding

This feature allows you to forward an incoming call to another phone number e.g. anther extension, a group or an external number. When call forwarding is active the display showed the icon is displayed in the screen.

The following call forwarding events can be configured:

Cancel: Call forwarding is deactivated.
Always: All incoming calls are immediately forwarded.
Busy: Incoming calls are forwarded when the phone is busy. (Note; for
this feature to work, Call Waiting must be deactivated on the handset)
No Answer: Incoming calls are forwarded when the phone is
not answered after a specific period.

To configure Call Forwarding

Select: Menu->Call Features->Call Forward.
Select the type of forward you want.
Use the navigation key to Enable or Disable the forward.
Use the down Navigation key and enter the phone number you want to
forward your calls to.
Press Save to save the changes.
When selecting No Answer forward, enter the time, in seconds that the
handset should ring before forwarding the call.
Once the forward has been configured you can toggle the forwarding
feature on and off by pressing the Forward button if configured or the
TRANSFER button while the phone is in idle state.

Note: By default all calls will divert to your voicemail if not answered after a specific time.

Call Waiting

This call feature allows your phone to accept other incoming calls to an extension already in an active call.

To enable/disable Call Waiting:

Select Menu->Call Features->Call Waiting.
Use the navigation keys or Disable/Enable soft key to active/inactive
call waiting.
Use the navigation key to select if a Tone is played while call waiting
is active.
Press Save soft keys to save the changes.

Call Transfer

Blind Transfer

- □ Press **Transfer Button** or **Transfer** soft key during the active conversation, the call will be on hold.
- ☐ Dial the extension or telephone number.
- □ Press the **Transfer Button** or **Transfer** soft key.

Attended Transfer

- □ Press **Transfer Button** or **Transfer** soft key during the active conversation, the call will be on hold.
- □ Dial the extension or telephone number and press **OK**.
- ☐ Wait for the 3rd party to answer and announce the call.
- □ Press the **Transfer Button** or **Transfer** soft key.

3-way Conference

To establish a conference:

- ☐ Press the **Conference** soft key during an active call.
- ☐ The first call is placed on hold.
- □ Dial the number to conference in and press the **Send** soft key or **OK** button.
- □ Wait for the 2nd party to answer.
- □ Press the **Conference** soft key.
- $\hfill \square$ Hang up to disconnect all parties.

Voicemail

Setting up your voicemail

Press the	Message	button, di	al *98 oi	r your	extension	number.

You will be directed to the Main Menu of your mailbox.
□ Select Option 1 to listen to your messages.
 Select Option 3 for personal options.

□ Exit press *

Personal Options

- ☐ Press 2 for admin options
 - Press 1 to change your password. (default is 777)
 - o Press 3 to change the prompt level.
 - o Press 4 to toggle date and time announcement on or off.
 - o Press 6 to toggle auto play on or off.
- □ Press 3 for personal greetings.
 - For extended absence greeting press 1.
 - $_{\odot}\;$ For personal greeting press 2.
 - o To record your name press 3.

Retrieving Voicemail Messages

When messages are left in your mailbox, the message lamp will come
on and the display will indicate that you have a new voice message.
To access your mailbox press the Message button or the Connect
soft key.
Press 1

While listening to voicemail messages:

Press any digit to skip to the end of the message
To replay the message press 4
To delete the message press 7
To save the message press 9

